



Pico Remotes

Hassle-free, wireless installation for your team.
Convenient control for your customers.



What is a Pico remote?



A Pico remote is a battery-powered, RF control. It communicates with a range of other Lutron wireless devices, including dimmers, switches, and shades, as well as with fans and audio integrated into a Lutron system.

Create an additional point of control by adding a Pico remote to a dimmer, switch, shade, fan, or Sonos Home Sound System. Installation takes just minutes.




Pico remote wall-mounting kit (sold separately)

What can a Pico remote do for you?

- Simplify installation. Attach a Pico remote to any wall surface without cutting holes, running wire, spackling, or repainting.
- Save time. Add wireless 3-way dimming or switch-like control where your customer needs it, in a fraction of the time it takes to install a wired 3-way control.
- Avoid callbacks. Pico remote is battery-powered, with an industry-leading 10-year battery life.

Your time is valuable




Adding a new control location with a Pico remote

1. Replace an existing switch with a Lutron wireless dimmer or switch
2. Associate the Pico remote to the dimmer or switch*
3. Attach the Pico remote to a wall, place it on a pedestal, or use it with a car visor clip

Tools needed: screwdriver and pliers

* You can also easily associate a Pico remote directly to Lutron shades.

15 minutes
or less



Adding a new control location with a 3-way switch

1. Run wire through a crawl space, attic, or fish through a wall
2. Cut a hole in drywall and install the wallbox
3. Wire the new control into the existing circuit
4. Repair the wall and paint it

Tools needed: screwdriver, wire stripper, drywall saw, fish tape, pliers

2-4 hours



What can a Pico remote do for your customers?

Tailor lighting, audio, fans, and more to their preferences.

With one touch, a customer can:

- Turn off all lights in a house
- Adjust multiple lights or shades at once
- Modify audio
- Control a ceiling fan

Create control locations exactly where they want them.

Mount on a tabletop pedestal or directly on a wall. Tabletop pedestals are available in single, double, and triple configurations.



Experience greater convenience.

In the hallway ...

Add control in high-traffic areas — such as long hallways — that lack a convenient control location.



Pico paddle remote with Pico remote wall-mounting kit (sold separately)



Pico remote with nightlight mounted to a Pico single pedestal (sold separately)

*Moon LED shown brighter than it actually appears.

... and the nursery,

Dim lights without getting up, for undisturbed bedtime routines.



Pico remote on Pico car visor clip

... and from the car.

Create a path of light home. Place a Pico remote on a car visor clip and turn on entry or foyer lights when coming home at night.



The Clear Connect wireless signal reliably works around corners and through walls.


Pico original remote

Control lighting, shades, audio, and ceiling fans with a touch. Create presets using the "Favorite" button.

Pico remote with 4 buttons

Create and recall zones and scenes.

Lighting control



Pico original remote for lights
PJ2-3BRL-GWH-L01

Shade control



Pico original remote for shades
PJ2-3BRL-GWH-S01

Zone control

Control multiple lights or shades; operates the same as a 3-button remote with raise/lower, but without a "Favorite" button



Lights model
PJ2-4B-GWH-L01


Scene control

Control lights or shades to preset levels; differs from a Pico scene keypad in that all devices associated to the top button will also be associated to the other three buttons.




Lights model
PJ2-4B-GWH-L31

Audio control



Pico remote for audio
PJ2-3BRL-GWH-A02

Fan control



Pico smart remote for fan control
PJ2-3BRL-GWH-F01

2-group control

Control two groups of lights, two groups of shades, or one group of lights/one group of shades.



Lights model
PJ2-4B-GWH-L21

4-group toggle

Toggles four loads on and off; designed for HomeWorks QS systems




Lights model
PJ2-4B-GWH-L41

Pico scene keypad

Control lights, shades, and audio. Create customized lightscapes for typical activities in a home — such as “entertain” or “relax”—with scene names pre-engraved on keypads. Autoconfigure and personalize keypads in the Lutron App for Caséta and RA2 Select systems.

2-button scene control



Pico bedside scene keypad
PJ2-2B-GWH-P02


	Ceiling lights	Table lamp	Shades
Home	100%	50%	Open
Away	Off	Off	Closed

Use the “Goodnight” button to turn lights off and lower shades in other rooms of the house and the “Alert” button to turn hallway lights on and raise living room shades, all without getting out of bed.

Pico paddle remote


A powerful control featuring simple on/off control and a familiar design that coordinates with the existing paddle switches in your customers’ homes.

Light control



Pico paddle remote
PJ2-PB-GWH

4-button scene control




Pico kitchen scene keypad
PJ2-4B-GWH-P02

	Ceiling lights	Island lights	Pendant	Shades
Bright	100%	100%	100%	Open
Cooking	100%	100%	50%	75% Open
Dining	20%	65%	50%	50% Open
Off	Off	Off	Off	Closed

Control all the kitchen lights with a single button press.


Light control with Diva smart dimmer



Pico paddle remote
PJ2-PB-GWH

Pico remotes for lights

Ordering Information




Pico remotes with nightlight for lights

Ordering Information



Build a Pico Model Number

PJ2-____-XXX-XXX



Button Configuration Codes:

Button Configurations	Code
2-button	2B
2-button with raise/lower	2BRL
3-button	3B
3-button with raise/lower	3BRL
4-button	4B

Button Marking Codes:

L01, L31, L21, LS21, L41

Color Codes:

Gloss Colors



Satin Colors




* Available in White, Black, Ivory and Light Almond only

** On and Raise buttons are White; Preset, Lower, and Off buttons are Gray

Build a Pico Model Number

PJN-____-XXX-L01



Button Configuration Codes:

Button Configurations	Code
2-button	2B
2-button with raise/lower	2BRL

Button Marking Codes:

L01

Color Codes:

Gloss Colors



Pico remotes for shades

Ordering Information

actual size
PJ2-3BRL-GWH-S06

2BRL	3BRL	3BRL	3BRL	3BRL	3BRL
Shade (icons) (S01)	Shade (icons) (S01)	Shade (text) (S02)	Blackout (S03)	Sheer (S04)	Blind (S05)
3BRL	3BRL	3BRL	4B*	4B*	4B*
Drapery (S07)	Horizontal Sheer Blind (S09)	Wood Blind (S10)	Shade (icons) (S01)	Blackout (2-group) (S21)	Blackout (scene) (S31)

actual size
PJ2-2B-GWH-S08


Pico remote for video screens

Ordering Information



Build a Pico Model Number

PJ2-____-XXX-XXX



Button Configuration Codes:

Button Configurations	Code
2-button with raise/lower	2BRL
3-button with raise/lower	3BRL
4-button	4B

Button Marking Codes:

S01, S02, S03, S04, S05, S06, S07, S09, S10, S21, S31

Color Codes:

Gloss Colors

Black GBL	Ivory GIV	Light Almond GLA	White GWH	White/Gray GWG**

Satin Colors

Biscuit TBI	Midnight TMN	Snow TSW

* Available in White, Black, Ivory and Light Almond only
** On and Raise buttons are White; Preset, Lower, and Off buttons are Gray

Build a Pico Model Number

PJ2-2B-XXX-S08



Button Configuration Codes:

Button Configurations	Code
2-button	2B

Button Marking Codes:

S08

Color Codes:

Gloss Colors

Black GBL	Ivory GIV	Light Almond GLA	White GWH

Satin Colors


Biscuit TBI	Midnight TMN	Snow TSW

Pico remote for audio

Ordering Information



actual size
PJ2-3BRL-GWH-A02



Pico remote for fan control

Ordering Information



actual size
PJ2-3BRL-GWH-F01



Build a Pico Model Number

PJ2-3BRL-XXX-A02



Button Configuration Codes:

Button Configurations
3-button with raise/lower

Code
3BRL

Button Marking Codes:

A02

Color Codes:

Gloss Colors



Satin Colors



Build a Pico Model Number

PJ2-3BRL-XXX-F01



Button Configuration Codes:

Button Configurations
3-button with raise/lower

Code
3BRL

Button Marking Codes:

F01

Color Codes:

Gloss Colors



Satin Colors



Pico scene keypads

Ordering Information

Pico remotes with 4 buttons

Ordering Information: lutron.com/custompico

Entry




actual size
Lights
PJ2-2B-GWH-P01

Bedside



actual size
Lights
PJ2-2B-GWH-P02

Family Room



actual size
Lights
PJ2-4B-GWH-P01

Kitchen



actual size
Lights
PJ2-4B-GWH-P02

Any Room




actual size
Lights
PJ2-4B-GWH-P03

Zone Controls




actual size
Lights
PJ2-4B-GWH-EL1




actual size
Shades
PJ2-4B-GWH-ES1

Scene Controls




actual size
Lights
PJ2-4B-GWH-EL2



actual size
Shades
PJ2-4B-GWH-ES2

Build a Pico Model Number

PJ2-____-XXX-XXX



Button Configuration Codes:

Button Configurations	Code
2-button	2B
4-button	4B

Button Marking Codes:

P01, P02, P03

Color Codes:

Gloss Colors


Black GBL	Ivory GIV	Light Almond GLA	White GWH

Satin Colors

Biscuit TBI	Midnight TMN	Snow TSW

Build a Pico Model Number

PJ2-4B-XXX-XXX



Button Configuration Codes:

Button Configurations	Code
4-button	4B

Button Marking Codes:

EL1, EL2, ES1, ES2

Color Codes:

Gloss Colors

Black GBL	Ivory GIV	Light Almond GLA	White GWH

Satin Colors

Biscuit TBI	Midnight TMN	Snow TSW

Pico remote accessories

Ordering Information




Single pedestal
L-PED1-WH



Double pedestal
L-PED2-WH



Triple pedestal
L-PED3-WH



Claro wallplate
CW-1-WH

- Provides a clean, screwless look
- Available in 1-6 openings



Wallplate bracket
PICO-WBX-ADAPT

- Use to surface-mount a Pico remote to a wall
- Required when mounting a Pico remote over a 120 V wallbox




Car visor clip
PICO-CAR-CLIP

- Insert the Pico remote into the clip for convenient control from your car

Pedestal Model Number

L-PEDX-XX




Color Codes:

Gloss Colors




Gloss Wallplate Model Number

CW-__-XX



Satin Wallplate Model Number

SC-__-XX



Color Codes:

Gloss Colors



Satin Colors



Pico remotes — flexibility

You can use a Pico remote with Lutron standalone dimmers and shades, as well as with the following Lutron systems

Caséta system



Pico paddle remote, Diva smart dimmer, and Serena shades

RadioRA 3 system



Pico original remote, Sunnata keypad, and Sivoia QS Triathlon shades

RA2 Select system



Pico scene keypad, Maestro dimmer, and Sivoia QS Triathlon shades

HomeWorks QS system



Pico original remote, Palladiom keypad, and Palladiom shades



The Lutron logo, Lutron, Caséta, Claro, Clear Connect, HomeWorks, Maestro, Palladiom, Pico, RadioRA 2, RA2 Select, Satin Colors, seeTouch, Serena, Sivoia QS, and Triathlon are trademarks or registered trademarks of Lutron Electronics Co., Inc., in the U.S. and/or other countries.

Sonos and Works with Sonos are trademarks or registered trademarks of Sonos, Inc.

lutron.com/pico

Lutron Electronics Co., Inc., 7200 Suter Road, Coopersburg, PA 18036-1299

Customer Assistance

Online: lutron.com/help | Email: support@lutron.com | Phone: 1.844.LUTRON1 (588.7661) — includes 24/7 technical support

© 09/2023 Lutron Electronics Co., Inc. | P/N 367-2821 REV D